Integrated Control Electronics

- **General Documents**
  - High-Level Overview
  - Enclosure Specifications
  - Event System Guide
  - PCB Mechanical Specifications
  - OEM Integration Guide
- **Module Specifications**
  - Master Board
  - Quad Temperature Controller
  - Current Controller & Peak Lock Servo
  - Current Controller & Offset Phase Lock Servo
- **Full Command List**
  - Overview of Commands and Basic Usage
  - Master Board
  - Common Commands to all Slave Boards
  - Common Laser Current Controller Commands
  - Quad Temperature Controller
  - Current Controller & Peak Lock Servo
  - Current Controller & Offset Phase Lock Servo
  - Power Breakout
- **Software**
  - Python-based GUI for controlling ICE (hosted on GitHub)
  - Example GUI Software (Windows x64 only and obsolete)

From:
https://www.vescent.com/manuals/ - **Product Manuals**

Permanent link:
https://www.vescent.com/manuals/doku.php?id=ice&rev=1424821330

Last update: **2021/08/26 14:26**