

Ziegler-Nichols Loop Tuning

Warning: There is the possibility for the loop to go unstable. Use caution as gain is increased.

- Set Proportional Gain (G_P) to low value - Turn off Integral and Differential Gain (G_I & G_D)

From:

<https://www.vescent.com/manuals/> - **Product Manuals**

Permanent link:

<https://www.vescent.com/manuals/doku.php?id=slice:z-n&rev=1554216211>

Last update: **2021/08/26 14:26**

