

ICE Platform Enclosure

Document Revision: 1.0

Document Last Updated on 2021/08/26 14:26

Please read [Limited Warranty](#) and [General Warnings and Cautions](#) prior to operating.

Description

The ICE Platform Enclosure contains the necessary [Master Control Board](#), communications ports, I/O, mounting hardware, and thermal management for supporting up to 8 daughter modules.



Absolute Maximum Ratings

Note: All modules designed to be operated in laboratory environment

Parameter	Rating
Environmental Temperature	>15°C and <30°C
Environmental Humidity	<60%
Environmental Dew Points	<15°C

Specifications

	ICE-MC1	Units
Input Power Requirements		
<html> </html> 5V line	>5	A
<html> </html> 15V line	>1.5	A
<html> </html> -15V line	>1.5	A
Maximum Power Consumption¹⁾		

TTL Serial

This provides a TTL (low-voltage) asynchronous serial interface (USART) to communicate with the ICE Platform. Note that this serial interface is **not** compatible with RS-232 signalling levels, as found on the COM ports of older PC's. The serial interface operates at 3.3V signalling levels, 115,200 Baud, 8N1 format (8 bit, no parity, 1 stop bit), and no flow control. Bus idle state is high (3.3V). The TXO (transmit out) and RXI (receive in) nomenclature is from the perspective of the device external to the Master Controller. TXO is for an external device transmitting data into the ICE Platform. RXI is for the ICE Platform sending data out to an external device. Either the TTL serial interface or USB can be used to receive commands, but **not** simultaneously (e.g. interleaved bytes).

Note: The ground pin of the D-Sub 9 connector is connected to the ground pin of the USB connector. The shell of the D-Sub 9 connector is connected to the chassis of the ICE Enclosure. Even though the D-Sub 9 interface is opto-isolated, there are potential ground connections between the D-Sub and USB port.

5V In

This pin is used to supply the isolated interface on the ICE Platform with power. It is only necessary to supply 5V on this pin if the USB port is left unconnected. If the USB port is connected to a computer, the isolated interface will be powered from the USB cable. Even if both the USB port is connected and 5V is supplied on this pin, no damage will occur. The maximum current draw on this pin is 10mA.

GPIO

The GPIO pins are used for event system signalling. Voltage signalling is at 3.3V, active low. Pin definitions and usage is detailed in the [Event System](#) section.

Safety Interlock BNC


The safety interlock signal prevents the Master Controller from releasing the safety interlocks on all attached daughter boards. The safety interlock is only applicable to daughter boards that have laser controllers. Without the safety interlocks released, daughter boards are prevented from powering on lasers. The safety interlock signal floats high to 3.3V and must be pulled down to ground to release the interlocks. This pin can be permanently shorted directly to ground if safety interlock functionality is not required.

1)

External power provided to ICE-MC1 must also be able to handle the current requirements to utilize maximum power consumption specification

2)

leave unconnected if USB is also connected



From:

<https://www.vescent.com/manuals/> - **Product Manuals**

Permanent link:

<https://www.vescent.com/manuals/doku.php?id=ice:enclosure&rev=1403905566>

Last update: **2021/08/26 14:26**

